

## UNIVERSAL MARKING STRIPS

### Installation instructions

A set consists of 85 strips 4 cm wide and 8 strips 5 cm wide.

Strip length: 1.60 m.

The 5 cm strips are intended for the center service line when used with the models numbered T1588.

- 1** Measuring the tennis court, marking the corners.
- 2** Laying the 1.60 m U-profile strips
- 3** Loosen the court slightly in the places where the sides of the U-shaped strips are to be pressed into the tennis court.
- 4** Now push the T-connectors into the bottom of the marking strips and connect them each with a further marking strip.
- 5** Then fit the strips into the designated position. Take care, as mentioned above, that the court is soft and well-loosened.
- 6** Lay the strips with an expansion joint measuring approx 1 cm. The joint allows a lengthening of the strips, also in times of hot weather.
- 7** Stamp the marking strips with a line stamper or a hand stamper (if available). Otherwise a hammer or a pickaxe (long flat underside) may also be used. Finally fix the lines firmly in place with the help of a light hand roller – not with a heavy motor roller.
- 8** Washing in or filling in the lines respectively with water or a brush – the line has to be stamped or rolled long enough until it lies completely flat on the court.
- 9** In no way should the strips be pressed in with force, the PVC profile must be able to be fixed into the ground with ease.