

Volleyball-Uprights DVW II with pulley mechanism

Congratulations! You decided to buy an original Haspo-Volleyball unit with testmark of the German Volleyball Association DVW II.

This unit is delivered completely mounted. So you have only to consider indications to concrete the ground sockets and some instructions.

Indications to concrete ground sockets:

1. Mount ground sockets according to the drawing. We recommend to place them negative-going by about 1° declination to the outside.
2. Do not apply an **acceleration mixture** or **antifreeze** as these adhesives may cause damages to the sockets.
3. The ground sockets have to be shortened correspondingly if the unit is used on plastic grounds or if special ground sockets for plastic grounds are used.

Instructions:

1. To survey the adjustment of net height, use self-adhesive marking foils. Stick uprights in the ground sockets, tension the net, measure the exact net height and put foils at the sides of the uprights.
Fix net rope at the mechanical upright as follows: Fix net rope in the snap hook of the tensioning cord at the pulley mechanism. Pull the lower cord up to the requested net tension. Fix cord in the clamcleat holder.
2. Tensioning of the net:
Fix net rope at the opposite upright as follows: Pull net rope over the roller and through the threaded ring eye situated above the handwheel. Then pull it back and clip it in the hook below the roller.
3. The lower net height fixing is done in the lower rails of each upright. Unfasten the crank to adjust net so that the rail can then be pushed to the desired height. Take care that the tensioning cords of the lower net fixing are straightly tensioned.
4. To remove the tension and the net:
Unfasten tensioning cord from clamcleat holder. Then take net from snap hook of tensioning cord. Pull down tensioning rope up to a distance of approx. 25 cm between top of the roller and the beginning of the pulley mechanism.
Take net from the opposite upright.
In order to ensure that the pulley mechanism cannot be damaged during storage of uprights pull tensioning cord through the snap hook and fix it in the clamcleat holder.

Safety advice/storage:

Storage of the uprights has to be effected horizontally on a board or on a special trolley.

When using the uprights pay attention that the fixing screws of the tensioning/holding device are fastened tightly so that they cannot back out during the installation into the ground sockets.

Maintenance instructions:

Please take care that from time to time all screwings have to be checked and in case fixed again.

.....and now enjoy yourself.