



**1** Each post is assembled from three pieces. The section with the FUNTEC sticker is the middle piece. The bottom section consists of a larger and smaller section. You can remove the short section of the post if required to reduce the net height to the recommended ladies height.




**2** Assemble the two parts of the yellow straps as shown. Make sure the loops are positioned at the ends of the belt and not near the metal clip lock. Place the small loops of the straps under the disks on the top of the four sand anchors.

**3** To obtain the ideal position for the sand anchors, unfold the net completely **1**. The loops at the ends of the top cable mark the places for the posts **2**. Drive the anchors into the ground at a distance of approx. 3.3m from the post position to form an angle of approx. 45deg with the post **3**. Please refer to figure 8 at the bottom of this page to get an overview of the correct placement of posts and anchors.



**4** Use two anchors per post. Make sure to knock the anchors into the ground at a slight angle away from the posts to aid tensioning.




**5** Put the loops on the other end of the straps over the top end of the posts and put the posts up sloping inwards. Then position the cable loops attached to the top ends of the net over the top of the posts as well.



**6** Elastic net centring: Connect the black elasticised cords at the top of the post with the red net cords at the top corners of the net ensuring they are under slight tension. The tension of the bungees will keep the net centred between the poles later.

**7** Tighten the yellow straps and adjust the position of the post as necessary to get the posts upright. The net should now align midway between the poles automatically but if not simply adjust the short red ropes at the top of the net to get it central. Adjust the lower ropes to length at the black hook end and attach them to the metal clip locks on the yellow tension straps.

**8** The net tension and net height can be altered to achieve the perfect net by adjusting the tension of the ropes at the bottom corners of the net.



**Hints**

- Wipe the sand off the posts before storing them.
- Store all anchors in one single pole section so they cannot drop out inside the bag.

**Recommendation**

We recommend the Beach Masters courtline as suitable for this portable Beachvolleyball set. It consists of 25mm blue strapping with elasticised corner ropes and plastic peg anchors.

**Parts list:**

Qu.	Description	Art.-ID
6	Plastic poles, 2 with a removable section	111414
6	Plastic connector parts	111401
2	Plastic post top parts	111402
2	Plastic base foot parts	111403
2	Elastic net centring cords	111419
4	Sand anchors	111408
4	Tension straps, 2-piece	111407
1	Fun net, 8.5m/9.5m	111324/111322
4	Black hooks	111413
1	Beach Bag	111332