





**Installation instruction for Street Workout**



A-A ( 1 : 4 )



**INTER-PLAY**



List of elements			
Position	Quantity	Number of part	Description
1	4		Plastic cover
2	2	ISO 10511	Nut self-locking M12
3	4	DIN 125	Washer M12
4	4		Plastic washer
5	4	DIN 440	Washer M12
6	1		Flat bar 210x70x6
7	1		Rubber washer 72x212
8	2	M12x120 kl. 8.8	hexagon bolt M12x120
9	1		Profil 80x80x3
10	1		Pipe fi 42,4x3,2

**Order of assembly:**

1. Choose a place for the device, bearing in mind that there should be a safety area, different for each model.
2. Remember about a safe surface (eg earth, sand, fine gravel, lawn), also in the protection zone around the device.
3. Dig the foundation pits for the device.
4. Assemble the device and insert the poles into the dug foundation pits.
5. Place from the bottom (eg with stones) so that the poles are buried and stabilize the entire structure.
6. Flood the foundation pits with B-20 concrete.
7. Again we check if the device is properly stabilized (horizontal, vertical).
8. We secure the area and wait a few days (depending on the weather, season) for the concrete foundations to harden.
9. After the concrete has hardened, cover (cover) the foundations with the top layer of the pavement, 30 cm thick.
10. The device can be put to use.